

Usage
Instructions

PVC Floor Bunding Installation Guide

WHAT YOU NEED

- PVC Floor Bunding - per metre (75H x 200W mm)
- 2 x Dynabolts (6.5 x 55mm)
- Fulaprene sealant tubes
- Caulk gun
- Permanent marker or chalk
- Hammer drill with masonry drill bit
- Fine tooth saw
- Socket set
- Vacuum cleaner or broom



INSTRUCTIONS

1. To begin, ensure that the installation surface is clean and free of oil and grease. The floor must be completely dry before beginning install for the Fulaprene to adhere effectively.
2. Mark out the floor where the floor bund is to be installed with a permanent marker or chalk
3. Using the line as a guide, measure the length required for each section of the bund and cut to match. Corner pieces can be purchased to change direction.
4. Liberally apply Fulaprene sealant underneath the floor bund and on the ends of each adjoining section
5. Place the prepared section of floor bund along the line, applying downward pressure until the full length has sealed. Cut foam back from join if necessary and overlap the PVC, ensuring a tight seal is formed by the glue.
6. If the floor bunding is in a high traffic area, use the aluminium strips along both edges of the bunding.
7. Using the hammer drill, insert a hole into the floor in line with the aluminium strips. Vacuum away resulting dust.
8. Insert dynabolts through the aluminium strips and tighten using the socket set until floor bund is fully secured
9. If necessary, run a bead of Fulaprene sealant along the inside edge of the bund to provide a final seal
10. Repeat this process until all lengths are in place and the bund has been created.
11. Floor bunding should not be installed on an upwards incline or be exposed to traffic for 24 hours after application

