


Usage
Instructions

Rubber Floor Bunding Installation Guide

WHAT YOU NEED

- Rubber Floor Bunding - metre lengths
- 2 x Dynabolts (8 x 100mm)
- Fulaprene sealant tubes
- Caulk gun
- Permanent marker or chalk
- Hammer drill with masonry drill bit
- Fine tooth saw
- Socket set
- Vacuum cleaner or broom



INSTRUCTIONS

1. To begin, ensure that the installation surface is clean and free of oil and grease. The floor must be completely dry before beginning install
2. Mark out the floor where the floor bund is to be installed with a permanent marker or chalk
3. Using the line as a guide, measure the length required for each section of the bund and cut to match. These can be mitred to change direction
4. Liberally apply Fulaprene sealant underneath the floor bund and on the ends of each adjoining section
5. Place the prepared section of floor bund along the line, applying downward pressure until the full length has sealed
6. Using the hammer drill, insert a 10mm diameter hole into the floor, approximately 70mm deep. Vacuum away resulting dust.
7. Insert dynabolts through the bunding and tighten using the socket set until floor bund is fully secured
8. Run a bead of Fulaprene sealant along the inside edge of the bund to provide a final seal
9. Repeat this process until all lengths are in place and the bund has been created
10. Floor bunding must not be exposed to traffic for 24 hours after application

